

# EBI 310 PDF Logger

-200 °C to +250 °C USB PDF temperature logger



Range, °C:	-200 °C to +250 °C
Accuracy:	± 2 °C (-200 °C ... -100 °C ) ± 1 °C (-100 °C ... -20 °C ) ± 0.2 °C (-20 °C ... +60 °C ) ± 0.5 °C (+60 °C ... +250 °C )
Divisions:	0,1 °C
Dimensions:	80 x 34 x 14 mm
Weight:	35 gr
Memory:	120000 values
Protection Class:	IP65
Measuring modes:	Start/Stop, endless loop, start with button
Measurement interval:	1min...24h

## Prices

Standard pricing is Flat Rate (no minimum rental period required).

Discounted pricing available on the basis of agreed minimum rental period upfront.

Available minimum rental terms are 6, 12, 18, 24, 36, 48 and 60 months.

For a suitable tailor made quotation, please contact us at:

- E: [sales@medicapitalrent.com](mailto:sales@medicapitalrent.com)
- T: +31 71 581 4 581

Should you require different technical specifications, please do not hesitate to contact us.

## Easy to Use

Temperature monitoring was never this easy: Just connect the data logger to the USB port of a PC and read out your measured data with any common PDF reader software.

## Start

Just press the "start" button and start logging: The EBI 310 is ready to monitor time and temperature. Once you remove your goods from storage or they reach their destination, you can see immediately if a temperature limit was exceeded with the help of a flashing red LED. MediCapital Rent can pre-programm the logger according to your requirements, or leave this to the site.

## Connect

Connect the logger to any PC after transport or removing the monitored goods from storage. The logger will automatically generate a standard PDF without any additional software.

## Inspect

Inspect time and temperature data for over limit conditions using any PDF reader software. The PDF can be stored, printed or emailed to any place you need.

## Optional Additional Services: Recalibration

MediCapital Rent will make sure that each temperature logger is sent with a valid calibration sheet. Should you want a yearly recalibration, we also can offer a Yearly Servicing option. After 50 weeks of the initial order, MediCapital Rent will ship a freshly calibrated temperature logger to the site and will arrange the pick-up of the old logger.

MediCapital Rent BV | Tieleman en Drosweg 17 - 19 | 2314 XW | Leiden  
The Netherlands | T. +31 (0)71 581 45 81 | F. +31 (0)71 581 4 582

MediCapital Rent INC | 101 TDK Boulevard, Suite F Peachtree City | GA 30269  
United States | T. +1 (678) 969 22 07 | F. +1 (770) 248 05 00

[info@medicapitalrent.com](mailto:info@medicapitalrent.com) | [www.medicapitalrent.com](http://www.medicapitalrent.com)



**MediCapital Rent**

Your reliable partner in clinical research